

ANT-6033N

Parabolic Antenna Assembly Guide

Package Included

No	Descriptions	Quantity
01	Dish	1x
02	Feeding Unit	1x
03	Antenna Mount Part -1	1x
04	Antenna Mount Part - 2	1x
05	Pole Mount Clamp -1	2x
06	Pole Mount Clamp -2	2x
07	M8 Washer	8x
80	M8 x 80mm Screw	4x
09	M8 x 15mm Screw	8x
10	M8 Flanşlı Nut	4x
11	M6 Washer	10x
12	M6 x 50mm Screw	4x
13	Cylinder Booster	4x
14	M6 x15mm Screw	2x
15	M6x20mm Screw	4x
16	Radio Mounting Bracket	1x



ANT- 6033N







Feeding Unit



Antenna Mount Part -1



Antenna Mount Part -2

0000

Booster x4



Pole Mount Clamp -1



Pole Mount Clamp -2





M8 Washer M8x80mm M8x15mm Screw x4



Screw x8



M8 Nuts x4





Screw x4

Ш



M6x15mm Screw x2



M6x20mm Screw x4



Radio Mounting Bracket



6033N Product Info



6033N Guide



+90 212 465 0 621 +90 212 672 32 05



sales@deltalink.com.tr www.deltalink.com.tr





ANT- 6033N

Parabolic Antenna Assembly Guide



In the supply assembly, the antenna will be mounted with the M6 x 20mm bolt and M6 nut, with the water drainage holes of the antenna facing down, and the arrow mark on the scale facing











M6x30mm long screws are inserted from inside to outside through 4 holes prepared in the antenna and fixed by screwing to the riser cylinders in return.











The screws of the lower round apparatus are loosened and separated, the iron mounting feet with the adjustment screws are passed through the twisting part and fixed using M8x15mm screws, the vertical adjustment screw is











M8x80mm screws are inserted into the slot by passing through the top and bottom holes, the connection piece is fixed to the holes on the iron apparatus by using M8x15mm screws and nuts.











The cylindrical risers on the bowl are fixed with M6 nuts, with the arrow on the pole connecting piece pointing upwards. It is fixed with M8 nut by attaching the counter during the pole connection.











Ready to Install





ANT- 6033N

Parabolic Antenna Assembly Guide

Part Placement (Assembly Expansion)

